


Operating instructions

ISOBUS Software

(FW E231 3165)



Company details

Wilhelm STOLL Maschinenfabrik GmbH

PO box 1181, D-38266 Lengede

Bahnhofstr. 21, D-38268 Lengede

Telephone: +49 (0) 53 44/20 222

Fax: +49 (0) 53 44/20 182

Email: info@stoll-germany.com

Web: www.stoll-germany.com

Spare Parts Order

Telephone: +49 (0) 53 44/20-144 and -266

Administration

Telephone: +49 (0) 53 44/20-145 and -146

Fax: +49 (0) 53 44/20-183

Email: parts@stoll-germany.com

Copyright

© Wilhelm STOLL Maschinenfabrik GmbH

Reproduction of these instructions, both completely and in excerpts, is only allowed with approval from Wilhelm STOLL Maschinenfabrik GmbH. Any infringement shall entail full compensation of damages and can be punishable by law.

The original instructions were written in the German language.

Instructions in other languages were translated from German.

Table of Contents

1	Start-up.....	3
1.1	Start procedure based on the example of the Deutz VT6150.4 TTV.....	3
2	Menu navigation.....	4
3	Page layout.....	5
3.1.1	Symbols.....	6
4	Menu pages.....	7
4.1	Driver profiles.....	7
4.2	Main page.....	7
4.2.1	Implement change.....	9
4.3	Weighing page.....	10
4.4	Implement selection.....	11
4.4.1	Available implements.....	11
4.5	Implement settings.....	12
4.5.1	Implement selection.....	13
4.6	Calibrating the weighing position.....	13
4.7	Setting the 3rd control circuit.....	14
4.8	Adjusting the working window.....	15
4.9	Return to position function.....	16
4.10	Setting the end position damping, speed mode and ramps.....	17
4.11	Lifting arm settings.....	19
4.12	Tip-over protection.....	19
4.13	Emergency page.....	20



1 Start-up

1.1 Start procedure based on the example of the Deutz VT6150.4 TTV

To be able to work with the front loader, the following steps must be performed each time the tractor is started.




Maximise the front loader page.

Activate AUX-N:  → 


Acknowledge any appearing AUX-N messages.

Open the Bucher Automation page 



Activate the front loader.

2 Menu navigation




3 Page layout

The active functions are shown on the status bar at the top edge of the screen.

On the right edge of the screen, there are up to 12 softkeys, depending on the active menu.

At the bottom edge of the screen, there is the display panel for the button assignment and the active level.



Input boxes



To change the value, tap on the box.
Inputs are made with the keypad.



Exit the page.









Save the parameter or exit without saving.













Navigate in the menu.

3.1.1 Symbols
















Symbols in the status bar

	Parallel leveling		Pressure control for 3rd control circuit
	Implement locking mechanism		Continuous mode for 3rd control circuit
	Weighing		Tip-over protection active / implement info

Symbols for the button assignment


	Weighing		3rd control circuit		Parallel leveling off
	Return to position		Float position		3rd control circuit page A
	Bucket shake		Load-independent lowering implement off		3rd control circuit page B
	Implement zero position				

Symbols for the menu pages

	Profiles		Implement selection		Emergency operation
	Main page		Implements setup		Diagnosis
	Weighing		Weighing setup		Lifting arm setup
	Working window		3rd control circuit setup		Calibration
	Return to position setup		Ramps and vibration damping		Emergency operation

4 Menu pages

4.1 Driver profiles



Current profile. Highlighted green.

Easy mode on/off

Current tractor profile


Here, a profile name with 10 letters can be assigned.

Pin the current profile. This page will then be skipped when the system is started.

Easy mode

In Easy mode, only a limited menu selection is available. Fixed values are set for the ramps, scaling, fine controls and end position damping.


4.2 Main page



Weighing is active.


Current weight

Selected implement with implement number



Top end position
Deviation from the horizontal position
Current position
Current position in degrees
Bottom end position

Activate the vibration damping.
Activate scaling for the lifting arm and implement (reduce speed).
Call up the implement settings and implement change.
Call up the Weighing page.



Activate system.
Implement unlocking
Activate parallel leveling.
Call up the Return to position page (memory).
Call up the working ranges.
Settings and diagnosis

Move to the memory position:

Press the button and move the joystick in the direction of the desired position.

Trigger the bucket shake:

Press the button and at the same time, move the implement axis using the joystick. The amplitude of motion is determined by moving the joystick.


Activate the 3rd control circuit:

Press the button and move the implement axis using the joystick.

Activate the float position:

When the float position is activated, press the button and move the joystick in the lowering direction (lifting arm or implement). Pressing the button again deactivates the float position.

4.2.1 Implement change



Procedure for implement unlocking and locking



Implement unlocking is only possible when the current position of the lifting arm is $\leq 25^\circ$.



When the softkey is actuated, it is highlighted blue.




By pressing on the symbol highlighted blue again, the lock will be opened. Unlocking of the 3rd control circuit is performed automatically by the system. The symbol is highlighted orange and indicates that the lock is open.




If the symbol highlighted orange is actuated, the lock is closed again. The symbol is highlighted black.

4.3 Weighing page



Weighing status
Implement calibrated
Implement weighing range
Lifting arm weighing range



Add up the weighing results.
The last measurement will be used for taring.
Delete the total quantity.
Delete the last weighing procedure.
Activate the weighing procedure.



Total weight
Number of weighing procedures
Target weight
Difference from the target weight

Triggering the weighing procedure

Press the softkey, move the joystick to the lifting position and hold it there. The lifting arm and implement move to the weighing range (Pos. 2/3 of the defined range). The status symbol flashes green. When the weighing position has been reached, the weighing procedure begins. The status symbol is constantly green. When the weighing procedure is complete, the status symbol disappears again. A successful weighing procedure is indicated with an acoustic signal. If the weighing procedure is aborted or an error occurs while weighing, the status symbol turns orange for 5 s. If the implement is not calibrated, the status symbol flashes orange for 5 s. The weighing counter and the weighing total are automatically saved.

To achieve the most precise weighing results possible, the following conditions should be met:

- Weigh on level ground.
- Do not weigh while driving.

4.4 Implement selection

Back to the main page

Implement no.

Implement type

Select the implement.

Call up the implement settings.

4.4.1 Available implements

Cutters / bale cutters	Bale grippers	Pallet forks	Log forks
<p>Nr. 1</p> <p>Type </p> <p>Name Sil. cut.</p>	<p>Nr. 2</p> <p>Type </p> <p>Name Bale clamp</p>	<p>Nr. 3</p> <p>Type </p> <p>Name Pal. fork</p>	<p>Nr. 4</p> <p>Type </p> <p>Name Log fork</p>

Bucket with grab	Buckets	Manure forks	Load lifters
<p>Nr. 5</p> <p>Type </p> <p>Name Grab buck.</p>	<p>Nr. 6</p> <p>Type </p> <p>Name Bucket</p>	<p>Nr. 7</p> <p>Type </p> <p>Name Manu. fork</p>	<p>Nr. 8</p> <p>Type </p> <p>Name Load lift</p>

Universal / third-party implements	Universal / third-party implements		
<p>Nr. 9</p> <p>Type </p> <p>Name Univers. 1</p>	<p>Nr. 10</p> <p>Type </p> <p>Name Univers. 2</p>		

4.5 Implement settings

Current top end position

Select implement type
Here, a name with 10 letters can be assigned.

Current bottom end position

Button assignment: tap T1..T6 and assign the function.

Exit the page with or without saving.

Reset all implement settings

Set the zero position. The current position will be adopted.

Activate the working ranges.

Go to the previous page.



Activate the end position damping.

Activate the load-independent lowering.

Activate flow sharing.

Set the top end position. The current position will be adopted.

Set the bottom end position. The current position will be adopted.


Go to the next page.

4.5.1 Implement selection


Mark the mounted implement and confirm.



The display depends on the display utilised in the vehicle.



4.6 Calibrating the weighing position



The weighing range is always 10° and cannot be changed.

4.7 Setting the 3rd control circuit


Activate the pressure control.
 Activate the continuous mode. Only possible when the pressure control is active!
 Adopt the current pressure as the pressure limit.
 Activate the 3rd control circuit.
 Activate the fine control with fixed value.

Current pressure
 Set pressure limit
 The pressure limit can be entered either using the keypad or the current pressure can be adopted with the softkey **Set P→I**.

For continuous mode, the volume flow can be pre-selected in % for the 3rd control circuit here.
 Set the priority for the 3rd control circuit.

Scaling low, medium, high
 100 % joystick movement corresponds to pre-defined speeds.

4.8 Adjusting the working window




Exit the page with or without saving.

Activate the lifting arm working window.

Set the top range.
Adopt the current position.

Set the bottom range.
Adopt the current position.



Activate the implement working window.


Set the top range.
Adopt the current position.

Set the bottom range.
Adopt the current position.



The implement range can only be deactivated when no working range is activated in the implement settings. For FZ IB+ front loaders, the implement range cannot be deactivated.

4.9 Return to position function



Positions for Memory 1
Move to position: press T5 and move the joystick in the lifting direction.

Positions for Memory 2
Move to position: press T5 and move the joystick in the lowering direction.


Linked mode: press T5 and move the joystick in the lift lifting arm (M1) or lower lifting arm (M2) direction. Move the lifting arm and implement to the defined position.

Exit the page with or without saving.

Activate the lifting arm memory positions.

Activate linked mode for Position 1.

Activate linked mode for Position 2.




Activate the implement memory positions.

Set memory positions M1.
Adopt the current position of the active function.

Set memory positions M2.
Adopt the current position of the active function.

4.10 Setting the end position damping, speed mode and ramps



	Low	Medium	High
End position damping	8°	15°	25°
Scaling	25 %	45 %	65 %
Start/stop ramps	200 ms	600 ms	1000 ms

End position damping


End position damping enables gentle movement to the end positions, without damaging the materials. The speed is automatically progressively reduced just before reaching the mechanical end position, until the end position is reached. 3 levels can be selected for starting the braking procedure.

Scaling

With the scaling, the speed can be reduced across the entire range. A value of 65 means a speed of 65 % for 100 % joystick movement.



The values set here are only active when they were activated on the main page with the softkey.




Start/stop ramps

The adjustable response behaviour function enables gentle starting and stopping of the movement. The specified time always refers to a target value jump of 100 %.

Example: with an entered time of 600 ms, the control signal reaches the maximum value for the control at 100 % joystick movement after 600 ms.

Joystick movement




Start ramp:
The joystick is moved,
the movement begins.

Stop ramp:
Joystick back in neutral position,
the movement stops.

Fine control

With the fine control, the valve movement can be reduced in the lower range of the joystick movement and therefore increase the resolution of the joystick in the lower range. 100 % speed is always reached at the maximum joystick movement. The smaller the value selected for the fine control, the finer the control in the lower range of the joystick movement.



4.11 Lifting arm settings


kg or lbs can be selected for the weight units

Reset the current profile to factory settings.

Activate float position. Is required to be able to activate the function.

Navigate in the Diagnosis menu.

4.12 Tip-over protection

The tip-over protection  symbol appears in the status bar when the following conditions are met:

- The angle of the lifting arm is greater than the lifting arm angle set for the tip-over protection and the total angle was reached. The implement then cannot be scooped any further.



The total angle consists of the angle of the lifting arm and the angle of the implements. The total angle determines the maximum lifting height. The limitation of the lifting height caused by the total angle aims to prevent hazards to the operator, e.g. by dumping the load on the tractor.

- The implement is at the upper mechanical stop. The lifting arm then cannot be lowered any further. (Only for FZ IB+ front loader).
- The implement type or name was changed in a different profile. The symbol disappears again after switching to the Implement selection menu.

4.13 Emergency page

On this page, the lifting arm, the implement and the 3rd control circuit can still be operated in case of failure of the joystick in the vehicle, for example.

